AIRPORT DIAGRAM

AL-50 (FAA)

BIRMINGHAM INTL (BHM)
BIRMINGHAM, ALABAMA



Rwy 24 ldg 8230′

RWY 6-24
S175, T205, ST175, TT350
RWY 18-36
S75, T170, ST175, TT240

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM
02332
BIRMINGHAM, ALABAMA
BIRMINGHAM INTL (BHM)